

# BETWEEN SERIES ADAPTERS



**Between Series Adapters**

# Between Series Adapters

## AMC Between Series Adapters

| Part Number | Description                         | Body Material         |
|-------------|-------------------------------------|-----------------------|
| 031-6101    | AMC Jack to TNC Jack R/P            | Brass, 2- Hole Flange |
| 031-6109    | AMC Jack to BNC Jack R/P (special)  | Brass                 |
| 031-6112    | AMC Jack to TNC Jack R/P (standard) | Brass, Bulkhead       |
| 901-10097   | AMC Jack to SMA Jack R/P            | Brass                 |

## MMCX Between Series Adapters

| Part Number    | Description           | Body Material          |
|----------------|-----------------------|------------------------|
| 908-31100      | MMCX Plug to SMA Jack | Brass/Beryllium Copper |
| APH-SMAJ-MMCXP | MMCX Plug to SMA Jack | Brass                  |
| 908-32101      | MMCX Jack to SMA Plug | Brass/Beryllium Copper |
| APH-SMAP-MMCXJ | MMCX Jack to SMA Plug | Brass                  |
| APH-SMAP-MMCXP | MMCX Plug to SMA Plug | Brass                  |
| APH-SMAJ-MMCXJ | MMCX Jack to SMA Jack | Brass                  |

## MCX Between Series Adapters

| Part Number   | Description          | Body Material |
|---------------|----------------------|---------------|
| APH-SMAP-MCXJ | MCX Jack to SMA Plug | Brass         |
| APH-SMAJ-MCXP | MCX Plug to SMA Jack | Brass         |
| APH-SMAP-MCXP | MCX Plug to SMA Plug | Brass         |
| APH-SMAJ-MCXJ | MCX Jack to SMA Jack | Brass         |

## 1.0/2.3 Between Series Adapters

| Part Number | Description              |                  |
|-------------|--------------------------|------------------|
| 901-10005   | 1.0/2.3 Jack to SMA Plug | Stainless Steel  |
| 901-10006   | 1.0/2.3 Plug to SMA Jack | Beryllium Copper |
| 901-10007   | 1.0/2.3 Plug to SMA Plug | Beryllium Copper |
| 901-10008   | 1.0/2.3 Jack to SMA Jack | Stainless Steel  |

## SMB Between Series Adapters

| Part Number   | Description          |                       |
|---------------|----------------------|-----------------------|
| 901-9033      | SMB Jack to SMA Jack | Stainless Steel       |
| APH-SMAJ-SMBJ | SMB Jack to SMA Jack | Brass                 |
| APH-SMAP-SMBJ | SMB Jack to SMA Plug | Brass                 |
| 901-9034      | SMB Plug to SMA Jack | Brass/Stainless Steel |
| APH-SMAJ-SMBP | SMB Plug to SMA Jack | Brass                 |
| 901-9038      | SMB Plug to SMA Plug | Brass/Stainless Steel |
| APH-SMAP-SMBP | SMB Plug to SMA Plug | Brass                 |

## SMA Between Series Adapters

| Part Number    | Description               | Body Material             |
|----------------|---------------------------|---------------------------|
| 131-91038      | SMA Plug to APC-7         | Beryllium Copper          |
| APH-SMAP-MMCXJ | SMA Plug to MMCX Jack     | Brass                     |
| 908-32101      | SMA Plug to MMCX Jack     | Beryllium Copper or Brass |
| APH-SMAJ-MMCXP | SMA Jack to MMCX Plug     | Brass                     |
| 908-31100      | SMA Jack to MMCX Plug     | Beryllium Copper or Brass |
| APH-SMAP-MMCXP | SMA Plug to MMCX Plug     | Brass                     |
| APH-SMAJ-MMCXJ | SMA Jack to MMCX Jack     | Brass                     |
| APH-SMAP-MCXP  | SMA Plug to MCX Plug      | Brass                     |
| APH-SMAJ-MCXJ  | SMA Jack to MCX Jack      | Brass                     |
| APH-SMAP-MCXJ  | SMA Plug to MCX Jack      | Brass                     |
| APH-SMAJ-MCXP  | SMA Jack to MCX Plug      | Brass                     |
| 901-10005      | SMA Plug to 1.0/2.3 Jack  | Stainless Steel           |
| 901-10006      | SMA Jack to 1.0/2.3 Plug  | Beryllium Copper          |
| 901-10007      | SMA Plug to 1.0/2.3 Plug  | Beryllium Copper          |
| 901-10008      | SMA Jack to 1.0/2.3 Jack  | Stainless Steel           |
| 901-10097      | SMA Jack R/P to AMC Jack  | Brass                     |
| APH-SMAP-SMBJ  | SMA Plug to SMB Jack      | Brass                     |
| APH-SMAJ-SMBP  | SMA Jack to SMB Plug      | Brass                     |
| 901-9034       | SMA Jack to SMB Plug      | Stainless Steel/Brass     |
| APH-SMAP-SMBP  | SMA Plug to SMB Plug      | Brass                     |
| 901-9038       | SMA Plug to SMB Plug      | Stainless Steel/Brass     |
| APH-SMAJ-SMBJ  | SMA Jack to SMB Jack      | Brass                     |
| 901-9033       | SMA Jack to SMB Jack      | Stainless Steel           |
| 930-100A-51S   | SMA Jack to QMA Jack      | Brass                     |
| 930-101A-51S   | SMA Jack to QMA Plug      | Brass                     |
| APH-SMAP-MUHFJ | SMA Plug to Mini UHF Jack | Brass                     |
| APH-SMAJ-MUHFP | SMA Jack to Mini UHF Plug | Brass                     |
| APH-SMAP-MUHFP | SMA Plug to Mini UHF Plug | Brass                     |
| APH-SMAJ-MUHFJ | SMA Jack to Mini UHF Jack | Brass                     |
| APH-SMAP-BNCJ  | SMA Plug to BNC Jack      | Brass                     |
| APH-SMAJ-BNCP  | SMA Jack to BNC Plug      | Brass                     |
| APH-SMAJ-BNCJ  | SMA Jack to BNC Jack      | Brass                     |
| APH-SMAP-BNCP  | SMA Plug to BNC Plug      | Brass                     |
| APH-SMAP-TNCJ  | SMA Plug to TNC Jack      | Brass                     |
| 901-168        | SMA Plug to TNC Plug      | Beryllium Copper/Brass    |
| APH-SMAP-TNCP  | SMA Plug to TNC Plug      | Brass                     |
| 901-171        | SMA Jack to TNC Jack      | Beryllium Copper/Brass    |
| APH-SMAJ-TNCJ  | SMA Jack to TNC Jack      | Brass                     |
| APH-SMAJ-TNCP  | SMA Jack to TNC Plug      | Brass                     |
| APH-SMAP-UHFJ  | SMA Plug to UHF Jack      | Brass                     |
| APH-SMAJ-UHFP  | SMA Jack to UHF Plug      | Brass                     |
| APH-SMAP-UHFP  | SMA Plug to UHF Plug      | Brass                     |
| APH-SMAJ-UHFJ  | SMA Jack to UHF Jack      | Brass                     |
| APH-SMAJ-NP    | SMA Jack to N Plug        | Brass                     |
| APH-SMAP-NP    | SMA Plug to N Plug        | Brass                     |
| APH-SMAJ-NJ    | SMA Jack to N Jack        | Brass                     |
| APH-SMAJ-NJBHD | SMA Jack to N Jack        | Brass                     |
| APH-SMAP-NJ    | SMA Plug to N Jack        | Brass                     |

# Between Series Adapters

## QMA Between Series Adapters

| Part Number  | Description          | Body Material |
|--------------|----------------------|---------------|
| 930-100A-51S | QMA Jack to SMA Jack | Brass         |
| 930-101A-51S | QMA Plug to SMA Jack | Brass         |

## Mini-UHF Between Series Adapters

| Part Number    | Description               | Body Material |
|----------------|---------------------------|---------------|
| 083-910-RFX    | Mini-UHF Plug to UHF Plug | Brass         |
| APH-SMAP-MUHFJ | Mini UHF Jack to SMA Plug | Brass         |
| APH-SMAJ-MUHFP | Mini UHF Plug to SMA Jack | Brass         |
| APH-SMAP-MUHFP | Mini UHF Plug to SMA Plug | Brass         |
| APH-SMAJ-MUHFJ | Mini UHF Jack to SMA Jack | Brass         |
| APH-MUHFP-UHFJ | Mini UHF Plug to UHF Jack | Brass         |

## Type F Between Series Adapters

| Part Number | Description                | Body Material |
|-------------|----------------------------|---------------|
| 531-40010   | Type F Jack to Type G Plug | Brass         |
| APH-BNCP-FJ | Type F Jack to BNC Plug    | Brass         |
| APH-NJ-FJ   | Type F Jack to Type N Jack | Brass         |
| APH-NJ-FP   | Type F Plug to Type N Jack | Brass         |

## Type G Between Series Adapters

| Part Number | Description                |       |
|-------------|----------------------------|-------|
| 531-40010   | Type G Plug to Type F Jack | Brass |

## BNC Between Series Adapters

| Part Number   | Description                        |       |
|---------------|------------------------------------|-------|
| 031-6109      | BNC Jack R/P to AMC Jack (special) | Brass |
| APH-BNCP-FJ   | BNC Plug To Type F Jack            | Brass |
| APH-SMAP-BNCJ | BNC Jack to SMA Plug               | Brass |
| APH-SMAJ-BNCP | BNC Plug to SMA Jack               | Brass |
| APH-SMAJ-BNCJ | BNC Jack to SMA Jack               | Brass |
| APH-SMAP-BNCP | BNC Plug to SMA Plug               | Brass |
| APH-BNCP-TNCJ | BNC Plug to TNC Jack               | Brass |
| APH-BNCJ-TNCP | BNC Jack to TNC Plug               | Brass |
| APH-BNCJ-TNCJ | BNC Jack to TNC Jack               | Brass |
| APH-BNCP-TNCP | BNC Plug to TNC Plug               | Brass |
| APH-BNCP-UHFJ | BNC Plug to UHF Jack               | Brass |
| 031-28        | BNC Jack to UHF Plug               | Brass |
| APH-BNCP-UHFP | BNC Plug to UHF Plug               | Brass |
| 000-2900      | BNC Plug to UHF Jack               | Brass |



**TNC Between Series Adapters**

| Part Number   | Description                         | Body Material          |
|---------------|-------------------------------------|------------------------|
| 031-6101      | TNC Jack R/P to AMC Jack            | Brass, 2-Hole Flange   |
| 031-6112      | TNC Jack R/P to AMC Jack (standard) | Brass, Bulkhead        |
| 901-168       | TNC Plug to SMA Plug                | Brass/Beryllium Copper |
| 901-171       | TNC Jack to SMA Jack                | Brass/Beryllium Copper |
| APH-SMAP-TNCJ | TNC Jack to SMA Plug                | Brass                  |
| APH-SMAJ-TNCP | TNC Plug to SMA Jack                | Brass                  |
| APH-SMAP-TNCP | TNC Plug to SMA Plug                | Brass                  |
| APH-SMAJ-TNCJ | TNC Jack to SMA Jack                | Brass                  |
| APH-BNCP-TNCJ | TNC Jack to BNC Plug                | Brass                  |
| APH-BNCJ-TNCP | TNC Plug to BNC Jack                | Brass                  |
| APH-BNCJ-TNCJ | TNC Jack to BNC Jack                | Brass                  |
| APH-BNCP-TNCP | TNC Plug to BNC Plug                | Brass                  |
| APH-NP-TNCJ   | TNC Jack to Type N Plug             | Brass                  |
| APH-NJ-TNCP   | TNC Plug to Type N Jack             | Brass                  |
| APH-NJ-TNCJ   | TNC Jack to Type N Jack             | Brass                  |
| APH-NP-TNCP   | TNC Plug to Type N Plug             | Brass                  |

**UHF Between Series Adapters**

| Part Number    | Description               | Body Material |
|----------------|---------------------------|---------------|
| 083-10         | UHF Jack to RCA Plug      | Brass         |
| APH-SMAP-UHFJ  | UHF Jack to SMA Plug      | Brass         |
| APH-SMAJ-UHFP  | UHF Plug to SMA Jack      | Brass         |
| APH-SMAP-UHFP  | UHF Plug to SMA Plug      | Brass         |
| APH-SMAJ-UHFJ  | UHF Jack to SMA Jack      | Brass         |
| APH-MUHFP-UHFJ | UHF Jack to Mini UHF Plug | Brass         |
| APH-BNCP-UHFJ  | UHF Jack to BNC Plug      | Brass         |
| APH-BNCP-UHFP  | UHF Plug to BNC Plug      | Brass         |
| 000-2900       | UHF Jack to BNC Plug      | Brass         |
| 031-28         | UHF Plug to BNC Jack      | Brass         |
| APH-NP-UHFJ    | UHF Jack to Type N Plug   | Brass         |
| 000-4400       | UHF Jack to N Plug        | Brass         |
| 000-14000      | UHF Plug to N Jack        | Brass         |
| 083-910-RFX    | UHF Plug to Mini-UHF Plug | Brass         |

# Between Series Adapters

## Type N Between Series Adapters

| Part Number    | Description                      | Body Material |
|----------------|----------------------------------|---------------|
| APH-SMAJ-NP    | Type N Plug to SMA Jack          | Brass         |
| APH-SMAJ-NJ    | Type N Jack to SMA Jack          | Brass         |
| APH-SMAP-NJ    | Type N Jack to SMA Plug          | Brass         |
| APH-SMAP-NP    | Type N Plug to SMA Plug          | Brass         |
| APH-SMAJ-NJBHD | Type N Bulkhead Jack to SMA Jack | Brass         |
| APH-NJ-FJ      | Type N Jack to Type F Jack       | Brass         |
| APH-NJ-FP      | Type N Jack to Type F Plug       | Brass         |
| APH-NP-BNCJ    | Type N Plug to BNC Jack          | Brass         |
| APH-NJ-BNCP    | Type N Jack to BNC Plug          | Brass         |
| APH-NJ-BNCJ    | Type N Jack to BNC Jack          | Brass         |
| APH-NP-BNCP    | Type N Plug to BNC Plug          | Brass         |
| APH-NP-TNCJ    | Type N Plug to TNC Jack          | Brass         |
| APH-NJ-TNCP    | Type N Jack to TNC Plug          | Brass         |
| APH-NJ-TNCJ    | Type N Jack to TNC Jack          | Brass         |
| APH-NP-TNCP    | Type N Plug to TNC Plug          | Brass         |
| 000-4400       | Type N Plug to UHF Jack          | Brass         |
| 000-14000      | Type N Jack to UHF Plug          | Brass         |
| APH-NP-UHFJ    | Type N Plug to UHF Jack          | Brass         |
| 000-16050      | Type N Jack to HN Plug           | Brass         |
| 000-16075      | Type N Plug to HN Jack           | Brass         |
| AFZ1-1         | Type N Jack to 7/16 Jack         | Brass         |
| AFZ2-1         | Type N Jack to 7/16 Plug         | Brass         |
| AFZ7-1         | Type N Plug to 7/16 Plug         | Brass         |

## HN Between Series Adapters

| Part Number | Description            | Body Material |
|-------------|------------------------|---------------|
| 000-16050   | HN Plug to Type N Jack | Brass         |
| 000-16075   | HN Jack to Type N Plug | Brass         |

## 7/16 Between Series Adapters

| Part Number | Description | Body Material |
|-------------|-------------|---------------|
| AFZ3-1      | Jack-Jack   | Brass         |
| AFZ4-1      | Plug-Plug   | Brass         |
| AFZ5-1      | Plug-Jack   | Brass         |

# Notes

| Cable Group | Cable Type                                                       |
|-------------|------------------------------------------------------------------|
| A           | RG-178, 196                                                      |
| B           | RG-174, 188A, 316, Belden 7805                                   |
| B1          | RG-179, 187, Belden 9221                                         |
| B2          | RD-188/U, RD-316/U                                               |
| B3          | RD-179/U, AT&T 19224L2                                           |
| C           | RG-58, 58A, 58C, 141, 303, LMR195, Belden 7806A, 9907            |
| C1          | RG-55, 142, 223, 400                                             |
| C2          | LMR200, Belden 7807A                                             |
| D           | RG-58/U Plenum, Thinnnet, RG-122/U, Belden 88240, 89907          |
| E           | RG-59, 62, 140, 210, Belden 8241, 8263, 8279, 9209               |
| E1          | RG-59/U 20 AWG center conductor, Belden 1426A, 1505A, 9100, 9278 |
| E2          | RD-59/U, Belden 8281, 9141, 9231                                 |
| E3          | RG-59/U Quad Shield, Belden 1152A                                |
| F           | RG-59/U Plenum, Belden 1560A, 9259, 82259, 89259, 88241          |
| F1          | RG-59/U Plenum 20 AWG center conductor, Belden 82108             |
| G1          | RG-6, 143, 212                                                   |
| G2          | 8X, LMR240, Belden 7808A, 9258                                   |
| G3          | LMR400, Belden 7810A, 8214, 9913                                 |
| G4          | RG-8, 8A, 9, 87A, 213, 214, 225, 393                             |
| G5          | RD-6/U                                                           |
| H           | RG-11                                                            |
| H1          | Belden 1694A, 9248                                               |
| H2          | Belden 1859A, 7731, 8213, 9292                                   |
| H3          | RG-54A/U                                                         |
| I           | AT&T 734A, Belden 1505A                                          |
| I2          | AT&T 735A, Belden 735A1                                          |
| J           | Quad 59 headend cable                                            |
| K           | LMR600                                                           |
| K2          | Belden 1695A                                                     |
| K3          | RG-122, 180, 195, Belden 1855, 1865A, 8218                       |
| L           | .141 semi-rigid, RG-402/U                                        |
| L2          | .085, .086, .087 semi-rigid, RG-405/U                            |
| L3          | .250 semi-rigid                                                  |
| L4          | .047 semi-rigid, Belden 1674                                     |
| M           | 1/2 inch annular corrugated                                      |
| M1          | 1 1/4 inch annular corrugated                                    |
| M2          | 1 5/8 inch annular corrugated                                    |
| M3          | 7/8 inch annular corrugated                                      |
| N           | 1/4 Helical                                                      |
| N1          | 3/8 Helical                                                      |
| N2          | 1/2 Helical                                                      |
| N3          | 7/8 inch SFC                                                     |
| P1          | .81 mm OD micro-cable                                            |
| P2          | 1.13 mm OD micro-cable, TCB-068                                  |
| P3          | 1.32 mm OD micro-cable                                           |
| P4          | 1.37 mm OD micro-cable                                           |



# Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

## Amphenol:

[APH-BNCP-UHFP](#) [APH-MUHFP-UHFJ](#) [APH-SMAJ-MUHFP](#) [APH-SMAJ-MUHFP](#) [APH-SMAJ-NJ](#) [APH-SMAJ-UHFJ](#)  
[APH-SMAJ-UHFP](#) [APH-SMAP-MUHFP](#) [APH-SMAP-UHFP](#)

Компания «Life Electronics» занимается поставками электронных компонентов импортного и отечественного производства от производителей и со складов крупных дистрибьюторов Европы, Америки и Азии.

С конца 2013 года компания активно расширяет линейку поставок компонентов по направлению коаксиальный кабель, кварцевые генераторы и конденсаторы (керамические, пленочные, электролитические), за счёт заключения дистрибьюторских договоров

Мы предлагаем:

- Конкурентоспособные цены и скидки постоянным клиентам.
- Специальные условия для постоянных клиентов.
- Подбор аналогов.
- Поставку компонентов в любых объемах, удовлетворяющих вашим потребностям.
- Приемлемые сроки поставки, возможна ускоренная поставка.
- Доставку товара в любую точку России и стран СНГ.
- Комплексную поставку.
- Работу по проектам и поставку образцов.
- Формирование склада под заказчика.
- Сертификаты соответствия на поставляемую продукцию (по желанию клиента).
- Тестирование поставляемой продукции.
- Поставку компонентов, требующих военную и космическую приемку.
- Входной контроль качества.
- Наличие сертификата ISO.

В составе нашей компании организован Конструкторский отдел, призванный помогать разработчикам, и инженерам.

Конструкторский отдел помогает осуществить:

- Регистрацию проекта у производителя компонентов.
- Техническую поддержку проекта.
- Защиту от снятия компонента с производства.
- Оценку стоимости проекта по компонентам.
- Изготовление тестовой платы монтаж и пусконаладочные работы.



Тел: +7 (812) 336 43 04 (многоканальный)

Email: [org@lifeelectronics.ru](mailto:org@lifeelectronics.ru)

[www.lifeelectronics.ru](http://www.lifeelectronics.ru)