

IQS213AEV02 Evaluation Kit User Guide







Contents

1	Intro	oduction	3
2	Star	ndalone Operation	3
	2.1	Self-side operation	3
	2.2	Projected-side operation	3
	2.2.	1 Advanced Auto-Off Warning	4
3	Data	a Streaming Operation	4
	3.1	Self-side operation	5
	3.2	Projected side operation	6
4	Prof	totype Board	7
	4.1	Prototype Board	7
5	Con	nmunications Interface	8
6	Refe	erence Designs	8





1 Introduction

This user guide describes the operation of the IQS213AEV02 Evaluation Kit.

The EV-Kit consists of the following parts:

1 x Main board

1 x Plug-in board

3 x Module boards

To visualize raw data from the EV-Kit, the main board can be interfaced to any personal computer with USB support and IQS213A software GUI (Graphical User Interface). The purpose of the IQS213AEV02 EV-Kit is to help application and development engineers in evaluating the IQS213A Proximity, Touch and Swipe sensor.

2 Standalone Operation



Figure 2.1 IQS213AEV02 main board

Select between the Projected and Self side with the jumper. Move the slide switch to the ON position.

2.1 Self-side operation

Ensure the jumper is placed on the Self-side selection of the pins. The red LED on the Self-side should turn on. Approach the sense buttons with a finger. When close to the sense buttons the blue Prox LED will turn on. Touch the sense buttons and the corresponding green Touch LED will turn on.

2.2 Projected-side operation

Ensure the jumper is placed on the Proj-side selection of the pins.

The red LED on the Proj-side should turn on.

Approach the sense buttons with a finger.

When close to the sense buttons the blue Prox LED will turn on.

Perform a Swipe action across all 3 sensors. Touch on the left/right sensor and drag to the opposite side.

The green Swipe LED should turn on (if not, try to swipe faster).



With the Swipe LED on, the green Touch LED will show touches on any of the 3 buttons. The Advanced Auto-Off Warning (AAOW) green LED could show false activation and disable all outputs.

2.2.1 Advanced Auto-Off Warning

In standalone operation the Advanced Auto-Off Warning (AAOW) timer is set to 10 minutes. When the timer reaches this a warning is given. 30 seconds after this a second warning will be given. 30 seconds after the second warning the device will switch off automatically (disable all outputs). (Thus after 11 minutes the device will switch off).

This timer is default set to clear on a touch event on any button. When communicating with the IQS213A this timer can be set to clear on a Prox event or disabled entirely.

3 Data Streaming Operation

Connect the CT210 or DS100 to the Self/Proj side of the IQS213AEV02 EV-Kit.



The IQS213A GUI looks as follow:

Figure 3.1 IQS213 GUI

This is version V1.0.0.140 available from the Azoteq website. Click <u>here</u> to go to the GUI download page. Install and run the software.

Connect the CT210/DS100 to the PC with a USB cable. Connect the IQS213AEV02 EV-Kit to the CT210/DS100 with a ribbon cable.





3.1 Self-side operation

Connect the ribbon cable to the IQS213AEV02 EV-Kit at the Self-side.

In the GUI, click the Start button.

The following window should pop-up:



Figure 3.2 Pop-up window user selection options

For the Self-side select the "Connected IQS213 Configuration" option as the EV-Kit has been designed for this selection and the IC has the suggested settings on it.

The Self-side data streaming is show below.



Figure 3.3 GUI with Self Capacitance selected

Evaluate this setup while streaming the data to the GUI. Various options on the right side of the GUI can be chosen to further evaluate the capabilities and features of this IC.





3.2 Projected side operation

Connect the ribbon cable to the IQS213AEV02 EV-Kit at the Proj (Projected)-side. In the GUI, click the Start button.

The following window should pop-up:



Figure 3.4 Pop-up window user selection options

For the Proj-side select the "Connected IQS213 Configuration" option as the EV-Kit has been designed for this selection and the IC has the suggested settings on it.

The Proj-side data streaming is show below.



Figure 3.5 GUI with Projected Capacitance selected

Evaluate this setup while streaming the data to the GUI. Various options on the right side of the GUI can be chosen to further evaluate the capabilities and features of this IC.





4 Prototype Board

The IQS213AEV02 EV-Kit also comes with a Prototype Board and 3 x Module Boards for rapid prototyping.



Figure 4.1 Prototype Board (center) and Module Boards (left, right and plugged into center board)

This is used for rapid prototyping. Simply wire this board into your current design and evaluate the performance with the GUI.

4.1 Prototype Board

This is basically a breakout board for the module board. Plug a module board into the Prototype board and configure it with the Azoteq USBProg software program available from the Azoteq website.

Please Note: Fuse bits can only be programmed once!

Here is an example of how the USBProg software looks like.

	A	zoteq USBProg	V6.3.2.8					×	
jile <u>D</u> evice <u>S</u> witch Mode <u>H</u> elp									
Options:	tions: IQS213				IC Data:				
ІС Туре	1zz 12z z2	z - 2CH SWIPE	1zz 12z z2z - 2CH SWIPE						
Capacitive Technology	Self Capac	Self Capacitance 🗸 🗸			Self Capacitance				
Float RX	No	No 🗸			No				
Output Logic	Active Low	(SW OD)	Active Low (SW OD)						
Halt Time	2.5s		2.5s						
Low Power (LP)	NP (Norma	NP (Normal Power) 🗸			NP (Normal Power)				
Proximity Threshold	3	3 🗸			3				
Touch Threshold Alternitives	No	No			No				
Touch Thresholds (CH1 & CH3)	4	4 ~			4				
Touch Thresholds (CH2)	4	4 ~			4				
Swipe UI	Single Dire	Single Direction 🗸			Single Direction				
Allow Zero States	ed v Not allowed								
Stop Swipe on Zero State	Not require	Not required 🗸 🗸			Not required				
Minimum State Time	1 Sample	1 Sample 🗸			1 Sample				
Charge Transfer Frequency	1MHz(Mutu	1MHz(Mutual) / 0.5MHz(Self) v			1MHz(Mutual) / 0.5MHz(Self)				
Pin 7 Output Selection	Touch	Touch 🗸			Touch				
AC Filter	Disabled	Disabled 🗸			Disabled				
ATI Base (All Channels)	75	75 🗸			75				
Target	Prox 320,	Prox 320, Touch 160 🗸			Prox 320, Touch 160				
Advanced Auto-Off	Enabled		~	Enabled					
Noise Detect	Disabled		~	Disabled					
I*C Debug	Disabled		~	Disabled					
Note: For more information regarding the function product, please refer to the applicable datasheet		Set Se	lection	00000000					
Messages: Compatible device(s) detected		Program Chip	Reset Selection	Package	Type:	MSOP 1	0	¥	
Configuration Tool 'CT210' detected		Read Chip	More Options 🔻	Bulk Pack	Packaging:			~	
I ² C Address : 44H Device ID : 2802		Clear Messages Part Number For Ordering Purposes: IQS			IQS213	000000000 MS	SR		
IQS213 selected IC data read successfully		Exit	Export Order Detai					?	

Figure 4.2 Azoteq USBProg Software





5 Communications Interface

The IQS213A IC communicates according to I²C communication protocol.

6 Reference Designs

The reference design for the main board is shown below.



Figure 6.1 Reference design for IQS213AEV02 Main Board





Appendix A Contact Information

	USA	Asia	South Africa
Physical Address	6507 Jester Blvd Bldg 5, suite 510G Austin TX 78750 USA	Rm2125, Glittery City Shennan Rd Futian District Shenzhen, 518033 China	109 Main Street Paarl 7646 South Africa
Postal Address	6507 Jester Blvd Bldg 5, suite 510G Austin TX 78750 USA	Rm2125, Glittery City Shennan Rd Futian District Shenzhen, 518033 China	PO Box 3534 Paarl 7620 South Africa
Tel	+1 512 538 1995	+86 755 8303 5294 ext 808	+27 21 863 0033
Fax	+1 512 672 8442		+27 21 863 1512
Email	info@azoteq.com	linayu@azoteq.com.cn	info@azoteq.com

Please visit <u>www.azoteq.com</u> for a list of distributors and worldwide representation.

The following patents relate to the device or usage of the device: US 6,249,089 B1; US 6,621,225 B2; US 6,650,066 B2; US 6,952,084 B2; US 6,984,900 B1; US 7,084,526 B2; US 7,084,531 B2; US 7,265,494 B2; US 7,291,940 B2; US 7,329,970 B2; US 7,336,037 B2; US 7,443,101 B2; US 7,466,040 B2 ; US 7,498,749 B2; US 7,528,508 B2; US 7,755,219 B2; US 7,772,781 B2; US 7,781,980 B2; US 7,915,765 B2; US 7,994,726 B2; US 8,035,623 B2; US RE43,606 E; US 8,288,952 B2; US 8,395,395 B2; US 8,531,120 B2; US 8,659,306 B2; US 8,823,273 B2; EP 1 120 018 B2; EP 1 206 168 B1; EP 1 308 913 B1; EP 1 530 178 A1; EP 2 351 220 B1; EP 2 559 164 B1; CN 1330853; CN 1783573; AUS 761094; HK 104 1401

IQ Switch[®], SwipeSwitch[™], ProxSense[®], LightSense[™], AirButton[™], ProxFusion[™], Crystal Driver[™] and the

logo are trademarks of Azoteq.

The information in this Datasheet is believed to be accurate at the time of publication. Azoteq uses reasonable effort to maintain the information up-to-date and accurate, but does not warrant the accuracy, completeness or reliability of the information contained herein. All content and information are provided on an "as is" basis only, without any representations or warranties, express or implied, of any kind, including representations about the suitability of these products or information for any purpose. Azoteq disclaims all warranties and conditions with regard to these products and information, including but not limited to all implied warranties and conditions of merchantability, fitness for a particular purpose, title and non-infringement of any third party intellectual property rights. Azoteq assumes no liability for any damages or injury arising from any use of the information or the product or caused by, without limitation, failure of performance, error, omission, interruption, defect, delay in operation or transmission, even if Azoteq has been advised of the possibility of such damages. The applications mentioned herein are used solely for the purpose of illustration and Azoteq makes no warranty or representation that such applications will be suitable without further modification, nor recommends the use of its products for application that may present a risk to human life due to malfunction or otherwise. Azoteq products are not authorized for use as critical components in life support devices or systems. No licenses to patents are granted, implicitly, express or implied, by estoppel or otherwise, under any intellectual property rights. In the event that any of the abovementioned limitations or exclusions does not apply, it is agreed that Azoteq's total liability for all losses, damages and causes of action (in contract, tort (including without limitation, negligence) will not exceed the amount already paid by the customer for the products, programs and services at any time or to move or discontinue a

www.azoteq.com/ip info@azoteq.com



ООО "ЛайфЭлектроникс"

ИНН 7805602321 КПП 780501001 Р/С 40702810122510004610 ФАКБ "АБСОЛЮТ БАНК" (ЗАО) в г.Санкт-Петербурге К/С 3010181090000000703 БИК 044030703

Компания «Life Electronics» занимается поставками электронных компонентов импортного и отечественного производства от производителей и со складов крупных дистрибьюторов Европы, Америки и Азии.

С конца 2013 года компания активно расширяет линейку поставок компонентов по направлению коаксиальный кабель, кварцевые генераторы и конденсаторы (керамические, пленочные, электролитические), за счёт заключения дистрибьюторских договоров

Мы предлагаем:

- Конкурентоспособные цены и скидки постоянным клиентам.
- Специальные условия для постоянных клиентов.
- Подбор аналогов.
- Поставку компонентов в любых объемах, удовлетворяющих вашим потребностям.
- Приемлемые сроки поставки, возможна ускоренная поставка.
- Доставку товара в любую точку России и стран СНГ.
- Комплексную поставку.
- Работу по проектам и поставку образцов.
- Формирование склада под заказчика.
- Сертификаты соответствия на поставляемую продукцию (по желанию клиента).
- Тестирование поставляемой продукции.
- Поставку компонентов, требующих военную и космическую приемку.
- Входной контроль качества.
- Наличие сертификата ISO.

В составе нашей компании организован Конструкторский отдел, призванный помогать разработчикам, и инженерам.

Конструкторский отдел помогает осуществить:

- Регистрацию проекта у производителя компонентов.
- Техническую поддержку проекта.
- Защиту от снятия компонента с производства.
- Оценку стоимости проекта по компонентам.
- Изготовление тестовой платы монтаж и пусконаладочные работы.



Тел: +7 (812) 336 43 04 (многоканальный) Email: org@lifeelectronics.ru

www.lifeelectronics.ru