

## DESCRIPTION

Demonstration circuit 647 is a 1.2MHz, SOT-23 DC/DC Converter featuring the LT<sup>®</sup>3467. The demo board demonstrates two separate DC/DC converters for different application needs. The Boost Circuit is designed to convert a 5V input to 12V output at 300mA maximum load. The SEPIC Circuit generates a constant 12V/300mA output with 10V~16V variable input. Both circuits are designed to demonstrate the soft start feature, advantages of the 1.2MHz switching frequency, the internal 42V/1.1A switch, wide input voltage range and small circuit size. These circuits are intended for space-conscious applications such

as digital cameras, cellular phones, palmtop computers and LCD displays. The 1.2MHz switching frequency, 1.1A integrated switch, small circuit size, and low component count makes the LT3467 suitable for use in many other applications, such as PC cards, miniature disk drives, xDSL power supplies, flash memory products and local 5V or 12V supplies.

**Design files for this circuit board are available. Call the LTC factory.**

LT is a registered trademark of Linear Technology Corporation

**Table 1. Performance Summary (T<sub>A</sub> = 25°C)**

PARAMETERS FOR BOOST CONVERTER	CONDITION	VALUE
Input Voltage		5V
Output Voltage V <sub>OUT</sub>	V <sub>IN</sub> = 5V, I <sub>OUT</sub> = 0A to 300mA	12V ±2%
Maximum Output Current		300mA
Typical Output Ripple V <sub>OUT</sub>	V <sub>IN</sub> = 5, I <sub>OUT</sub> = 300mA	55mV <sub>P-P</sub>
Typical efficiency	V <sub>IN</sub> = 5, I <sub>OUT</sub> = 300mA	86%
PARAMETERS FOR SEPIC CONVERTER	CONDITION	VALUE
Minimum Input Voltage		10V
Maximum Input Voltage		16V
Output Voltage V <sub>OUT</sub>	V <sub>IN</sub> = 10V to 16V, I <sub>OUT</sub> = 0A to 300mA	12V ±2%
Maximum Output Current		300mA
Typical Output Ripple V <sub>OUT</sub>	V <sub>IN</sub> = 10V, I <sub>OUT</sub> = 300mA	50mV <sub>P-P</sub>
Typical efficiency	V <sub>IN</sub> = 10V to 16V, I <sub>OUT</sub> = 300mA	80%

## QUICK START PROCEDURE

Demonstration circuit 647 is easy to set up to evaluate the performance of the LT3467. Refer to Figure 1 for proper measurement equipment setup and follow the procedure below:

NOTE: When measuring the input or output voltage ripple, care must be taken to avoid a long ground lead

on the oscilloscope probe. Measure the input or output voltage ripple by touching the probe tip directly across the V<sub>IN</sub> or V<sub>OUT</sub> and GND terminals. See Figure 2 for proper scope probe technique.

NOTE: Steps 1-4 are for Boost Converter only.

1. Place jumper in the following positions:

# QUICK START GUIDE FOR DEMONSTRATION CIRCUIT 647

## 1.2MHZ, SOT-23 DC/DC CONVERTER

**JP1** On

2. With power off, connect the input power supply to  $V_{IN}$  and GND.
3. Turn on the power at the input.

**NOTE:** Make sure that the input voltage does not exceed 5V.

4. Check for the proper output voltages.

**NOTE:** If there is no output, temporarily disconnect the load to make sure that the load is not set too high.

**NOTE:** Once the proper output voltages are established, adjust the loads within the operating range and observe the output voltage regulation, ripple voltage, efficiency and other parameters directly across the  $V_{IN}$  or  $V_{OUT}$  and GND terminals. See Figure 2 for proper scope probe technique.

**NOTE:** Steps 5-9 are for Sepic converter only.

5. Place jumper in the following positions:

**JP2** On

6. With power off, connect the input power supply to  $V_{IN}$  and GND.
7. Turn on the power at the input.

**NOTE:** Make sure that the input voltage is set between 10V and 16V.

8. Check for the proper output voltages.

**NOTE:** If there is no output, temporarily disconnect the load to make sure that the load is not set too high.

9. Once the proper output voltages are established, adjust the loads within the operating range and observe the output voltage regulation, ripple voltage, efficiency and other parameters.




Figure 1. Proper Measurement Equipment setup





Figure 2. Measurement Input or Output Ripple

# QUICK START GUIDE FOR DEMONSTRATION CIRCUIT 647

## 1.2MHZ, SOT-23 DC/DC CONVERTER



**LINEAR TECHNOLOGY CORPORATION**  
 1630 MCCARTHY BLVD.  
 MILPITAS, CA 95035  
 (408) 432-1900 (408) 434-0507 FAX

Title: **1.2MHz, SOT-23 DC/DC Converter**

Size	Document Number	Rev
	DC647A	LT3467ES6

Date: Tuesday, February 18, 2003 Sheet 1 of 1

Компания «Life Electronics» занимается поставками электронных компонентов импортного и отечественного производства от производителей и со складов крупных дистрибьюторов Европы, Америки и Азии.

С конца 2013 года компания активно расширяет линейку поставок компонентов по направлению коаксиальный кабель, кварцевые генераторы и конденсаторы (керамические, пленочные, электролитические), за счёт заключения дистрибьюторских договоров

Мы предлагаем:

- Конкуренеспособные цены и скидки постоянным клиентам.
- Специальные условия для постоянных клиентов.
- Подбор аналогов.
- Поставку компонентов в любых объемах, удовлетворяющих вашим потребностям.
- Приемлемые сроки поставки, возможна ускоренная поставка.
- Доставку товара в любую точку России и стран СНГ.
- Комплексную поставку.
- Работу по проектам и поставку образцов.
- Формирование склада под заказчика.
- Сертификаты соответствия на поставляемую продукцию (по желанию клиента).
- Тестирование поставляемой продукции.
- Поставку компонентов, требующих военную и космическую приемку.
- Входной контроль качества.
- Наличие сертификата ISO.

В составе нашей компании организован Конструкторский отдел, призванный помогать разработчикам, и инженерам.

Конструкторский отдел помогает осуществить:

- Регистрацию проекта у производителя компонентов.
- Техническую поддержку проекта.
- Защиту от снятия компонента с производства.
- Оценку стоимости проекта по компонентам.
- Изготовление тестовой платы монтаж и пусконаладочные работы.



Тел: +7 (812) 336 43 04 (многоканальный)

Email: [org@lifeelectronics.ru](mailto:org@lifeelectronics.ru)