

**AMP**AMP INCORPORATED  
HARRISBURG, PA 17105

REDUCED FOR PACKAGING

**IS 9382**AMP\*  
INSERTION/EXTRACTION TOOL

453850-1

CUSTOMER HOTLINE  
1 800 722-1111RELEASED  
4-24-90

INSERTION/EXTRACTION TOOL PART NUMBER	RECEPTACLE PART NUMBERS	
	STRIP	LOOSE PIECE
453850-1	61119	61276
	61323	61513
	350393	350189
	640259	640024

**1. INTRODUCTION**

AMP Insertion/Extraction Tool 453850-1 is designed to insert and extract the AMP .058-Dia printed circuit (pc) board receptacles listed in Figure 1.

**NOTE**

All dimensions on this sheet are in inches.

Fig. 1

**2. DESCRIPTION**

The insertion/extraction tool, which is essentially a pair of tweezers with specifically designed tips, features a red dielectric coating in the area which is grasped by the operator. The tool tips grip the receptacle for insertion and extraction, thereby eliminating the strain that would normally be placed upon the crimped portion of the terminated wire if it were grasped for insertion or extraction of the receptacle.




Fig. 2

**3. INSERTION/EXTRACTION PROCEDURES (Figure 2)**

**A. Insertion**

After terminating the receptacle to the wire, proceed with the tool as follows:

1. Place the receptacle in the tool tips as illustrated, with the tool tips resting against the receptacle shoulder closest to the pc board.
2. Guide the receptacle onto the desired pin and apply moderate pressure on the tool to seat the receptacle on the pin until the edge of the receptacle is bottomed on the shoulder of the pin.
3. Release pressure on the tool, allowing the tips to expand, and withdraw the tool from the installed receptacle.

**B. Extraction**

1. Grasp the tool and maneuver the tool tips over the barrel portion of the receptacle as illustrated.
2. With the tool tips resting against the shoulder of the receptacle as illustrated, squeeze the tool and pull the receptacle straight off the pin.

**4. MAINTENANCE**

The tool requires little maintenance other than to wipe it with a clean, soft cloth periodically and to store it in a clean, dry area when not in use.

Insertion/Extraction Tool 453850-1, as described, is inspected prior to shipment and should conform to the information provided in Figure 3. Additional tools may be purchased from:

AMP Incorporated  
 P.O. Box 3608  
 Harrisburg, PA 17105-3608

or a wholly-owned subsidiary of AMP Incorporated.




Fig. 3

Компания «Life Electronics» занимается поставками электронных компонентов импортного и отечественного производства от производителей и со складов крупных дистрибьюторов Европы, Америки и Азии.

С конца 2013 года компания активно расширяет линейку поставок компонентов по направлению коаксиальный кабель, кварцевые генераторы и конденсаторы (керамические, пленочные, электролитические), за счёт заключения дистрибьюторских договоров

Мы предлагаем:

- Конкурентоспособные цены и скидки постоянным клиентам.
- Специальные условия для постоянных клиентов.
- Подбор аналогов.
- Поставку компонентов в любых объемах, удовлетворяющих вашим потребностям.
- Приемлемые сроки поставки, возможна ускоренная поставка.
- Доставку товара в любую точку России и стран СНГ.
- Комплексную поставку.
- Работу по проектам и поставку образцов.
- Формирование склада под заказчика.
- Сертификаты соответствия на поставляемую продукцию (по желанию клиента).
- Тестирование поставляемой продукции.
- Поставку компонентов, требующих военную и космическую приемку.
- Входной контроль качества.
- Наличие сертификата ISO.

В составе нашей компании организован Конструкторский отдел, призванный помогать разработчикам, и инженерам.

Конструкторский отдел помогает осуществить:

- Регистрацию проекта у производителя компонентов.
- Техническую поддержку проекта.
- Защиту от снятия компонента с производства.
- Оценку стоимости проекта по компонентам.
- Изготовление тестовой платы монтаж и пусконаладочные работы.



Тел: +7 (812) 336 43 04 (многоканальный)

Email: [org@lifeelectronics.ru](mailto:org@lifeelectronics.ru)