


Figure 1

1. INTRODUCTION

SMA Hermetically-Sealed Panel Feedthrough Jack Receptacles 1053159-1, 1053181-1, 1053182-1, 1053226-1, 1053227-1, 1053254-1, 1061372-1, and 1089139-1 are designed to be mounted onto a panel using the following tools:

TOOL DESCRIPTION	PART NUMBER CROSS-REFERENCE	
	TE CONNECTIVITY	M/A-COM
Step Reamer	1055284-1	2098-0442-54
.250-36, UNS-2B Bottoming Tap†	--	2098-5618-54
Torque Tool	1055251-1	2098-0248-54
3/8-in. Open Wrench†	--	--

† Commercially available



Unless otherwise specified, dimensions in this instruction sheet are in metric units [with U.S. customary units in brackets].

Reasons for reissue of this instruction sheet are provided in Section 5, REVISION SUMMARY.

2. DESCRIPTION

The jack receptacle consists of a jack and metal gasket. See Figure 1.

3. ASSEMBLY PROCEDURE



Follow safety precautions included with the tools used for assembly.

1. Refer to Figure 2, and drill a hole in the panel to the diameter shown. Using the step reamer, ream the hole to the depth shown. Using the bottoming tap, tap the thread to the depth shown.

2. While holding the collet of the torque tool, turn the handle clockwise until it stops. Thread the jack into the tool until it bottoms inside the tool. Hand-tighten the jack. Refer to Figure 3.



The torque tool is preset between 2.60 and 3.05 Nm [23 and 27 in.-lb].

Recommended Panel Cutout

Note: Dimensions are in inches over millimeters.




Figure 2




Figure 3

3. Install the metal gasket onto the jack. See Figure 4.




Figure 4

4. Thread the jack into the connector housing by turning the handle of the torque tool clockwise until the handle releases. See Figure 5, Detail A.
5. While holding the collet of the torque tool with the open wrench, turn the handle counter-clockwise, and remove the jack assembly from the torque tool. See Figure 5, Detail B.
6. Install the jack assembly onto the panel.

4. REPLACEMENT AND REPAIR

Discard and replace any defective or damaged jack receptacles or metal gaskets.

5. REVISION SUMMARY

Since the previous version of this document, the following changes were made:

- Updated document to corporate requirements.




Figure 5

Компания «Life Electronics» занимается поставками электронных компонентов импортного и отечественного производства от производителей и со складов крупных дистрибьюторов Европы, Америки и Азии.

С конца 2013 года компания активно расширяет линейку поставок компонентов по направлению коаксиальный кабель, кварцевые генераторы и конденсаторы (керамические, пленочные, электролитические), за счёт заключения дистрибьюторских договоров

Мы предлагаем:

- Конкурентоспособные цены и скидки постоянным клиентам.
- Специальные условия для постоянных клиентов.
- Подбор аналогов.
- Поставку компонентов в любых объемах, удовлетворяющих вашим потребностям.
- Приемлемые сроки поставки, возможна ускоренная поставка.
- Доставку товара в любую точку России и стран СНГ.
- Комплексную поставку.
- Работу по проектам и поставку образцов.
- Формирование склада под заказчика.
- Сертификаты соответствия на поставляемую продукцию (по желанию клиента).
- Тестирование поставляемой продукции.
- Поставку компонентов, требующих военную и космическую приемку.
- Входной контроль качества.
- Наличие сертификата ISO.

В составе нашей компании организован Конструкторский отдел, призванный помогать разработчикам, и инженерам.

Конструкторский отдел помогает осуществить:

- Регистрацию проекта у производителя компонентов.
- Техническую поддержку проекта.
- Защиту от снятия компонента с производства.
- Оценку стоимости проекта по компонентам.
- Изготовление тестовой платы монтаж и пусконаладочные работы.



Тел: +7 (812) 336 43 04 (многоканальный)
Email: org@lifeelectronics.ru