

# Power Supply IC Series for TFT-LCD Panels 12V Input Multi-channel System Power Supply IC



BD8160AEFV

No.09035EBT01

### Description

The BD8160AEFV is a system power supply for the TFT-LCD panels used for liquid crystal TVs.

Incorporates two high-power FETs with low on resistance for large currents that employ high-power packages, thus driving large current loads while suppressing the generation of heat. A charge pump controller is incorporated as well, thus greatly reducing the number of application components.

#### Features

- 1) Step-up and step-down DC/DC converter
- 2) Incorporates 2.6 A N-channel FET.
- 3) Incorporates positive/negative charge pumps.
- 4) Input voltage limit: 8 V to 18 V
- 5) Feedback voltage: 1.162 V ± 1%
- 6) Switching frequency: 500 kHz / 750kHz
- 7) Protection circuit: Under voltage lockout protection circuit Thermal shutdown circuit Overcurrent protection circuit Short Circuit Protection Overvoltage protection circuit for VS voltage (Boost DC/DC output)
- 8) HTSSOP-B28 Package

# Applications

Power supply for the TFT-LCD panels used for LCD TVs

#### ●Absolute maximum ratings (Ta = 25°C)

Parameter	Symbol	Rating	Unit	
Supply Voltage	SUP,VIN	20	V	
Power Dissipation	Pd	4700*	mW °C	
Operating Temperature Range	Topr	-40~+85		
Storage Temperature Range	Tstg	-55~+150	C°	
Junction Temperature	Tjmax	150	S°	
SW Voltage	Vsw	21	V	
SWB Voltage	Vswb	19	V	
EN1,EN2 Voltage	VEN1,VEN2	19	V	

\* Derating in done 37.6mW/°C for operating above Ta≧25°C(On 4-layer 70.0mm × 70.0mm × 1.6mm board)

#### ●Recommendable Operation Range (Ta=25°C)

Parameter	Symbol		Unit		
	Symbol	Min	Min Typ Ma		Offic
Supply Voltage	SUP,VIN	8	12	18	V
Vs Voltage	Vs	VIN+2	15	18	V
Switch current for SW	Isw	—	—	2.6**	А
Switch current for SWB	Iswв	—	—	2.0**	А
EN1,EN2,FREQ Voltage	VEN1, VEN2, VFREQ	_	_	18	V

\*\* Pd, ASO should not be exceeded

# Electrical characteristics (unless otherwise specified VIN=12V and Ta=25°C) 1. DC/DC converter controller block

Parameter	Symbol	Limits			Unit	Conditions	
Parameter	Symbol	Min	Тур	Max	Unit	Conditions	
Soft start – SS							
SS source current	I <sub>so</sub>	6	10	14	μA	V <sub>SS</sub> =0.5V	
Error amplifier block – FB and FBB							
FB and FBB input bias current	I <sub>FB12</sub>	-	0.1	2	μA		
Feedback voltage for boost converter	V <sub>FB</sub>	1.150	1.162	1.174	V	Voltage follower	
Feedback voltage for buck converter	$V_{FBB}$	1.188	1.213	1.238	V		
SW block – SW							
On resistance N-channel	R <sub>ONN</sub>	-	0.2	0.3	Ω	I <sub>O</sub> =0.8A	
Leak current N-channel	I <sub>LEAKN1</sub>	-	0	10	μA	V <sub>SW</sub> =18V	
Switch current limit for SW	I <sub>SW</sub>	2.6	-	-	А		
Maximum duty cycle	MDUTY	75	90	97	%	FB= 0V	
SW block – SWB							
On resistance N-channel	R <sub>ONH</sub>	-	0.2	0.3	Ω	I <sub>O</sub> =0.8A	
Leak current N-channel	I <sub>LEAKN2</sub>	-	0	10	μA	V <sub>INB</sub> =18V , V <sub>SWB</sub> =0V	
Switch current limit for SWB	I <sub>SWB</sub>	2.0	-	-	А		
Protections							
Over Voltage Protection for SW	VSWOVP	18.5	19	19.5	V		

# 2. Charge pump driver block

Parameter	Symbol	Limits			Unit	Conditions
	Symbol	Min	Тур	Max	Unit	Conditions
Error amplifier block – FBP and FBN						
FBP, FBN input bias current	I <sub>FBP,</sub> I <sub>FBN</sub>	-	0.1	1	μA	
Feedback voltage for VGH	$V_{FBP}$	1.188	1.213	1.238	V	
Feedback voltage for VGL	V <sub>FBN</sub>	0.18	0.2	0.22	V	
Delay start block						
DLY1, DLY2 source current	I <sub>DLY1,</sub> I <sub>DLY2</sub>	2	5	9	μA	V <sub>DLY</sub> =0.5V
DRP, DRN block						
On resistance N-channel	R <sub>ONN</sub>	-	5	-	Ω	I <sub>O</sub> =20mA
On resistance P-channel	R <sub>ONP</sub>	-	3	-	Ω	I <sub>O</sub> =20mA

# ●Electrical characteristics (unless otherwise specified VIN=12V and Ta=25°C)

3. General

Parameter	Symbol	Limits			Unit	Conditions
	Symbol	Min	Тур	Max	Unit	Conditions
Supply current						
Average supply current	I <sub>CC</sub>	-	5	8	mA	
Oscillator						
Oscillation frequency1	F <sub>OSC1</sub>	600	750	900	kHz	FREQ = High
Oscillation frequency2	F <sub>OSC2</sub>	400	500	600	kHz	FREQ = low
Protections						
Under voltage lockout threthold1	V <sub>UVLO1</sub>	6.9	7.4	7.9	V	VIN rising
Under voltage lockout threthold2	V <sub>UVLO2</sub>	6.5	7.0	7.5	V	VIN falling
Thermal Shutdown	T <sub>TSD</sub>	-	175	-	°C	<b>*</b> 1
Short Circuit Protection Time 1	T <sub>SCP1</sub>	153	219	285	ms	FREQ = High
Short Circuit Protection Time 2	T <sub>SCP2</sub>	230	328	426	ms	FREQ = Low
FB threshold1 for SCP	V <sub>FBSCP1</sub>	0.985	1.065	1.145	V	FB rising
FB threshold2 for SCP	V <sub>FBSCP2</sub>	-	0.969	-	V	FB falling
FBB threshold1 for SCP	V <sub>FBBSCP1</sub>	-	1.055	-	V	FBB rising
FBB threshold2 for SCP	V <sub>FBBSCP2</sub>	-	0.874	-	V	FBB falling
FBP threshold1 for SCP	V <sub>FBPSCP1</sub>	-	0.967	-	V	FBP rising
FBP threshold2 for SCP	V <sub>FBPSCP2</sub>	-	0.859	-	V	FBP falling
FBN threshold1 for SCP	V <sub>FBNSCP1</sub>	-	0.406	-	V	FBN falling
FBN threshold2 for SCP	V <sub>FBNSCP2</sub>	-	0.505	-	V	FBN rising
Reference Voltage						
Reference Voltage	V <sub>REF</sub>	1.188	1.213	1.238	V	
Gate Drive						
Gate drive threshold	V <sub>GD</sub>	0.985	1.065	1.145	V	
GD output low voltage	V <sub>OL</sub>	-	0.7	1.4	V	I=1mA
GD output leakage current	I <sub>LK</sub>	-	0	10	μA	
Logic signals EN1, EN2, FREQ						
High level input voltage	V <sub>IH</sub>	2.0	-	-	V	
Low level input voltage	VIL	-	-	0.8	V	

\* This product is not designed for protection against radioactive rays.

#### Reference Data (Unless otherwise specified, Ta = 25°C)



# Reference Data (Unless otherwise specified, Ta = 25°C)



#### Block Diagram AVIN os GD UVLO VREG TSD CURRENT SENSE OVP VREF REF OCP sw SW OSC FREQ s EN2 DRV Ś SOFT PGND SLOPE SS START CURRENT SENSE ſ OCP VINB ERF FB VINB s EN1 -DRV SWB COMP SLOPE SOFT START ۴Ŋ 4 воот FBB < SUP w EN1 DETECTOR Short Circuit Protection FB FBB FBP FBN > PG EN2 툰 SUP Ŷ ۰d۱ POSITIVE DRP CHARGE FBP PUMP Λ EN2 SUP ₹ √ NEGATIVE DRN CHARGE FBN PUMP יך לי DLY 1 IDLY ¢√IDLY IDLY 2 DLY 2 4 GND

Fig.22 Block Diagram

#### Typical Application



Fig.23 Typical Application

# Pin Assignment Diagram



Fig. 24 Pin Assignment Diagram

# Pin Assignment and Pin Function

Pin No.	Pin name	Function	Pin No.	Pin name	Function
1	FB	Feedback input 1 for VS	15	FBB	Feedback input for Vlogic
2	COMP	Error amp output	16	EN1	Enable pin for Vlogic and VGL
3	OS	Output sense pin	17	BOOT	Capacitance connection pin for booting
4	SW	Switching pin for VS	18	SWB	Switching pin for Vlogic
5	SW	Switching pin for VS	19	N.C.	Non-connect pin
6	PGND	Ground pin	20	VINB	Power supply input pin
7	PGND	Ground pin	21	VINB	Power supply input pin
8	SUP	Power supply input pin	22	AVIN	Power supply input pin
9	EN2	Enable pin for VS and VGH	23	GND	Analog Ground pin
10	DRP	Switching pin for VGH	24	REF	Internal reference output pin
11	DRN	Switching pin for VGL	25	DLY1	Delay start capacitance connection pin for VGL
12	FREQ	Frequency	26	DLY2	Delay start capacitance connection pin for VS
13	FBN	Feedback input 1 for VGL	27	GD	Gate drive pin for load switch
14	FBP	Feedback input 1 for VGH	28	SS	Soft start capacitance connection pin for VS

# Block Operation

• VREG

A block to generate constant-voltage for DC/DC boosting.

• VREF

A block that generates internal reference voltage of 2.9 V (Typ.).

• TSD/UVLO

TSD (Thermal shutdown)/UVLO (Under Voltage Lockout) protection block. The TSD circuit shuts down IC at 175°C (Typ.) The UVLO circuit shuts down the IC when the Vcc is 7 V (Typ.) or below.

• Error amp block (ERR)

This is the circuit to compare the reference voltage and the feedback voltage of output voltage. The COMP pin voltage resulting from this comparison determines the switching duty. At the time of startup, since the soft start is operated by the SS pin voltage, the COMP pin voltage is limited to the SS pin voltage.

Oscillator block (OSC)

This block generates the oscillating frequency.

SLOPE block

This block generates the triangular waveform from the clock created by OSC. Generated triangular waveform is sent to the PWM comparator.

PWM block

The COMP pin voltage output by the error amp is compared to the SLOPE block's triangular waveform to determine the switching duty. Since the switching duty is limited by the maximum duty ratio which is determined internally, it does not become 100%.

# DRV block

A DC/DC driver block. A signal from the PWM is input to drive the power FETs.

• CURRENT SENSE

Current flowing to the power FET is detected by voltage at the CURRENT SENSE and the overcurrent protection operates at 2.0/2.6A (min.). When the overcurrent protection operates, switching is turned OFF and the SS pin capacitance is discharged.

DELAY START

A start delay circuit for positive/negative charge pump and Boost converter.

• Soft start circuit

Since the output voltage rises gradually while restricting the current at the time of startup, it is possible to prevent the output voltage overshoot or the rush current.

Positive charge pump

A controller circuit for the positive-side charge pump. The switching amplitude is controlled so that the feedback voltage FBP will be set to 1.213 V (Typ.).

The start delay time can be set in the DLY2 pin at the time of startup. When the DLY2 voltage reaches 0.65 V (Typ.), switching waves will be output from the DRP pins.

Negative charge pump

A controller circuit for the negative-side charge pump. The switching amplitude is controlled so that the feedback voltage FBN will be set to 0.2 V (Typ.).

The start delay time can be set in the DLY1 pin at the time of startup. When the DLY2 voltage reaches 0.65 V (Typ.), switching waves will be output from the DRN pins.

Over Voltage protection of the Boost Converter

The boost converter has an overvoltage protection to protect the internal power MOS FET (SW) in case the feed back (FB) pin is floating or shorted to GND. Vs voltage is monitored with comparator over the OS pin. When the voltage of OS pin reached 19V (typ.), the Boost Converter stops its switching until the OS pin voltage falls below the comparator threshold.

### Start-up Sequence

The DC/DC converter of this IC incorporates a soft start function, and the charge pump incorporates a delay function, for which independent time settings are possible through external capacitors.

As the capacitance, 0.01  $\mu$ F to 0.1  $\mu$ F is recommended. If the capacitance is set lower than 0.01  $\mu$ F, the overshooting may occur on the output voltage. If the capacitance is set larger than 0.1  $\mu$ F, the excessive back current flow may occur in the internal parasitic elements when the power is turned OFF and it may damage IC. When the capacitor more than 0.1  $\mu$ F is used, be sure to insert a diode to VIN in series, or a bypass diode between the SS and VIN pins.



Fig.25 Example of Bypass Diode Use

When there is the activation relation (sequences) with other power supplies, be sure to use the high-precision product (such as X5R). Soft start time may vary according to the input voltage, output loads, coils, voltage, and output capacitance. Be sure to verify the operation using the actual product.

A delay of the charge pump starts from a point where V<sub>LOGIC</sub> reaches 85% of its nominal value (Typ.).

Soft start time of DC/DC converter block: tss Tss = (Css  $\times$  0.6V) / 10 µA [s]

Where, Css is an external capacitor.

Delay time of charge pump block: t DELAY t DELAY = (Css  $\times 0.65$ ) / 5µA [s] Where, Css is an external capacitor.

Startup example



Fig. 26 Output Timing Sequence with EN2 always high (EN2=VIN)



Fig. 27 Output Timing Sequence(with using EN1 and EN2)

### Short Circuit Protection

BD8160AEFV has a short circuit protection feature to prevent the large current flowing when the output is shorted to GND. This function is monitoring  $V_S$ ,  $V_{LOGIC}$ , VGH and VGL voltage and starts the timer when at least one of the outputs is not operating properly (when the output voltage was lower than expected) After TBD ms (Typ) of this abnormal state, BD8160AEFV will shutdown the all outputs and latch the state.

The timer operation will be done even when BD8160AEFV starts up. Therefore, please adjust the capacitor for SS, DLY1 and DLY2 (Softstart and Delaystart) so that the all output voltage reach the expected value within the Short Circuit Protection Time (TBD ms Typ)



Fig. 28

# Selecting Application Components

(1) Output LC constant (Boost Converter)

The inductance L to use for output is decided by the rated current ILR and input current maximum value IOMAX of the inductance.



Adjust so that IOMAX +  $\Delta$ IL does not reach the rated current value ILR. At this time,  $\Delta$ IL can be obtained by the following equation.

$$\Delta IL = \frac{1}{L} \times Vcc \times \frac{Vo-Vcc}{Vo} \times \frac{1}{f} [A]$$

Set with sufficient margin because the inductance L value may have the dispersion of  $\pm$  30%. For the capacitor C to use for the output, select the capacitor which has the larger value in the ripple voltage VPP

permissible value and the drop voltage permissible value at the time of sudden load change.

Output ripple voltage is decided by the following equation.

$$\Delta VPP = ILMAX \times RESR + \frac{1}{fCo} \times \frac{Vcc}{Vo} \times (ILMAX - \frac{\Delta IL}{2}) [V]$$

Perform setting so that the voltage is within the permissible ripple voltage range.

For the drop voltage VDR during sudden load change, please perform the rough calculation by the following equation.

$$V_{DR} = \frac{\Delta I}{Co} \times 10 \ \mu s$$
 [V]

However, 10 µs is the rough calculation value of the DC/DC response speed.

Make Co settings so that these two values will be within the limit values.

#### (2) Output LC constant (Buck Converter)

The inductance L to use for output is decided by the rated current ILR and input current maximum value IOMAX of the inductance.



Adjust so that IOMAX +  $\Delta$ IL does not reach the rated current value ILR. At this time,  $\Delta$ IL can be obtained by the following equation.

$$\Delta IL = \frac{1}{L} \times (Vcc - Vo) \times \frac{Vo}{Vcc} \times \frac{1}{f} [A]$$

Set with sufficient margin because the inductance L value may have the dispersion of  $\pm$  30%.

For the capacitor C to use for the output, select the capacitor which has the larger value in the ripple voltage VPP permissible value and the drop voltage permissible value at the time of sudden load change.

Output ripple voltage is decided by the following equation.

$$\Delta VPP = \Delta IL \times RESR + \frac{\Delta IL}{2Co} \times \frac{Vo}{Vcc} \times \frac{1}{f} [V]$$

Perform setting so that the voltage is within the permissible ripple voltage range.

For the drop voltage VDR during sudden load change, please perform the rough calculation by the following equation.

$$DR = \frac{\Delta I}{Co} \times 10 \ \mu s [V]$$

However, 10  $\mu s$  is the rough calculation value of the DC/DC response speed. Make Co settings so that these two values will be within the limit values.

ν

#### (3) Phase compensation

#### Phase Setting Method

The following conditions are required in order to ensure the stability of the negative feedback circuit.

•Phase lag should be 150° or lower during gain 1 (0 dB) (phase margin of 30° or higher).

Because DC/DC converter applications are sampled using the switching frequency, the overall GBW should be set to 1/10 the switching frequency or lower. The target application characteristics can be summarized as follows:

- •Phase lag should be 150° or lower during gain 1 (0 dB) (phase margin of 30° or higher).
- •The GBW at that time (i.e., the frequency of a 0-dB gain) is 1/10 of the switching frequency or below.

In other words, because the response is determined by the GBW limitation, it is necessary to use higher switching frequencies to raise response.

One way to maintain stability through phase compensation involves canceling the secondary phase lag (-180°) caused by LC resonance with a secondary phase advance (by inserting 2 phase advances).

The GBW (i.e., the frequency with the gain set to 1) is determined by the phase compensation capacitance connected to the error amp. Increase the capacitance if a GBW reduction is required.



The error amp performs phase compensation of types (a) and (b), making it act as a low-pass filter. For DC/DC converter applications, R refers to feedback resistors connected in parallel. From the LC resonance of output, the number of phase advances to be inserted is two.



Set a phase advancing frequency close to the LC resonant frequency for the purpose of canceling the LC resonance.

(4) Design of Feedback Resistance constant Set the feedback resistance as shown below.



(5) Positive-side Charge Pump Settings

The IC incorporates a charge pump controller, thus making it possible to generate stable gate voltage.

The output voltage is determined by the following equation. As the setting range,  $10k\Omega$  to  $330k\Omega$  is recommended. If the resistor is set lower than  $10k\Omega$ , it causes reduction of power efficiency. If it is set more than  $330k\Omega$ , the offset voltage becomes larger by the input bias current of  $0.1\mu A$  (Typ.) in the internal error amp.



By connecting capacitance to the DLY2 pin, the rising delay time can be set for the positive-side charge pump output. The delay time is determined by the following equation.

•Delay time of charge pump block t DELAY t DELAY = (CDLS  $\times$  0.65) / 5  $\mu$ A [s] Where, CDLS is an external capacitor.

(6) Negative-side Charge Pump Settings

BD8160AEFV incorporates a charge pump controller for negative voltage, thus making it possible to generate stable gate voltage.

The output voltage is determined by the following equation. As the setting range,  $10k\Omega$  to  $330k\Omega$  is recommended. If the resistor is set lower than  $10k\Omega$ , it causes reduction of power efficiency. If it is set more than  $330k\Omega$ , the offset voltage becomes larger by the input bias current of  $0.1\mu$ A (Typ.) in the internal error amp.



Like the positive-side charge pump, the rise delay time can be set by connecting capacitance to the DLY1 pin.

### •Selecting the Feedforward Capacitor (Boost Converter)

Across the upper resistor  $R_1$ , a bypass capacitor is needed to have a stable converter loop.  $C_1$  will set a zero in the loop together with  $R_1$ .



The regulator loop can be compensated by adjusting the exfernal components connected to the COMP pin.  $C_2, R_2$  are decided by the following formula.

 $Fz_1=11kHZ = \frac{1}{2 \times \pi \times C_2 \times R_2}$ 

#### •Selecting the Feedforward Capacitor (Buck converter)

The feedforward capacitor across the upper feedback resistor divider sets a zero in the control loop.



Fig.40

# ●I/O Equivalent Circuit Diagram

Vcc + + PVcc		
	SW REG	
2.COMP 24.REF 1.I	.FB 13.FBN 14.FBP 15.FBB	27.GD
9.EN2 12.FREQ 16.EN1 10	0.DRP 11.DRN	4.SW 5.SW
3.OS	· · · · · · · · · · · · · · · · · · ·	

Fig.41

# Notes for use

1) Absolute maximum ratings

Use of the IC in excess of absolute maximum ratings such as the applied voltage or operating temperature range may result in IC damage. Assumptions should not be made regarding the state of the IC (short mode or open mode) when such damage is suffered. A physical safety measure such as a fuse should be implemented when use of the IC in a special mode where the absolute maximum ratings may be exceeded is anticipated.

2) GND potential

Ensure a minimum GND pin potential in all operating conditions.

3) Setting of heat

Use a thermal design that allows for a sufficient margin in light of the power dissipation (Pd) in actual operating conditions.

4) Pin short and mistake fitting

Use caution when orienting and positioning the IC for mounting on printed circuit boards. Improper mounting may result in damage to the IC. Shorts between output pins or between output pins and the power supply and GND pins caused by the presence of a foreign object may result in damage to the IC.

5) Actions in strong magnetic field

Use caution when using the IC in the presence of a strong magnetic field as doing so may cause the IC to malfunction.

6) Testing on application boards

When testing the IC on an application board, connecting a capacitor to a pin with low impedance subjects the IC to stress. Always discharge capacitors after each process or step. Ground the IC during assembly steps as an antistatic measure, and use similar caution when transporting or storing the IC. Always turn the IC's power supply off before connecting it to or removing it from a jig or fixture during the inspection process.

7) Ground wiring patterns

When using both small signal and large current GND patterns, it is recommended to isolate the two ground patterns, placing a single ground point at the application's reference point so that the pattern wiring resistance and voltage variations caused by large currents do not cause variations in the small signal ground voltage. Be careful not to change the GND wiring patterns of any external components.

8) Regarding input pin of the IC

This monolithic IC contains P+ isolation and P substrate layers between adjacent elements in order to keep them isolated. P/N junctions are formed at the intersection of these P layers with the N layers of other elements to create a variety of parasitic elements. For example, when the resistors and transistors are connected to the pins as shown in Fig.42, a parasitic diode or a transistor operates by inverting the pin voltage and GND voltage. The formation of parasitic elements as a result of the relationships of the potentials of different pins is an inevitable result of the IC's architecture. The operation of parasitic elements can cause interference with circuit operation as well as IC malfunction and damage. For these reasons, it is necessary to use caution so that the IC is not used in a way that will trigger the operation of parasitic elements such as by the application of voltages lower than the GND (P substrate) voltage to input and output pins.



Fig. 42 Example of a Simple Monolithic IC Architecture

#### 9) Overcurrent protection circuits

An overcurrent protection circuit designed according to the output current is incorporated for the prevention of IC damage that may result in the event of load shorting. This protection circuit is effective in preventing damage due to sudden and unexpected accidents. However, the IC should not be used in applications characterized by the continuous operation or transitioning of the protection circuits. At the time of thermal designing, keep in mind that the current capacity has negative characteristics to temperatures.

10) Thermal shutdown circuit (TSD)

This IC incorporates a built-in TSD circuit for the protection from thermal destruction. The IC should be used within the specified power dissipation range. However, in the event that the IC continues to be operated in excess of its power dissipation limits, the attendant rise in the chip's junction temperature Tj will trigger the TSD circuit to turn off all output power elements. Operation of the TSD circuit presumes that the IC's absolute maximum ratings have been exceeded. Application designs should never make use of the TSD circuit.

11) Testing on application boards

At the time of inspection of the installation boards, when the capacitor is connected to the pin with low impedance, be sure to discharge electricity per process because it may load stresses to the IC. Always turn the IC's power supply off before connecting it to or removing it from a jig or fixture during the inspection process. Ground the IC during assembly steps as an antistatic measure, and use similar caution when transporting or storing the IC.

12) EN1 terminal

EN1 terminal should be pulled up to VIN terminal.

# Power Dissipation



# On $70 \times 70 \times 1.6$ mm glass epoxy PCB

(1) 1-layer board (Backside copper foil area 0 mm  $\times$  0 mm)

(2) 2-layer board (Backside copper foil area 15 mm  $\times$  15 mm)

(3) 2-layer board (Backside copper foil area 70 mm  $\times$  70 mm)

(4) 4-layer board (Backside copper foil area 70 mm  $\times$  70 mm)

# Ordering part number



# **HTSSOP-B28**



	Notes
	g or reproduction of this document, in part or in whole, is permitted without the ROHM Co.,Ltd.
The conte	nt specified herein is subject to change for improvement without notice.
"Products	nt specified herein is for the purpose of introducing ROHM's products (hereinafte "). If you wish to use any such Product, please be sure to refer to the specifications be obtained from ROHM upon request.
illustrate tl	of application circuits, circuit constants and any other information contained herein the standard usage and operations of the Products. The peripheral conditions mus nto account when designing circuits for mass production.
However,	e was taken in ensuring the accuracy of the information specified in this document should you incur any damage arising from any inaccuracy or misprint of sucl n, ROHM shall bear no responsibility for such damage.
examples implicitly, a other parti	cal information specified herein is intended only to show the typical functions of and of application circuits for the Products. ROHM does not grant you, explicitly o any license to use or exercise intellectual property or other rights held by ROHM and ies. ROHM shall bear no responsibility whatsoever for any dispute arising from the h technical information.
equipment	icts specified in this document are intended to be used with general-use electronic t or devices (such as audio visual equipment, office-automation equipment, commu evices, electronic appliances and amusement devices).
The Produ	cts specified in this document are not designed to be radiation tolerant.
	HM always makes efforts to enhance the quality and reliability of its Products, a ay fail or malfunction for a variety of reasons.
against the failure of a shall bear	sure to implement in your equipment using the Products safety measures to guard e possibility of physical injury, fire or any other damage caused in the event of the any Product, such as derating, redundancy, fire control and fail-safe designs. ROHM no responsibility whatsoever for your use of any Product outside of the prescribed of in accordance with the instruction manual.
system wh may result instrumen fuel-contro any of the	incts are not designed or manufactured to be used with any equipment, device of hich requires an extremely high level of reliability the failure or malfunction of which is in a direct threat to human life or create a risk of human injury (such as a medican t, transportation equipment, aerospace machinery, nuclear-reactor controller obler or other safety device). ROHM shall bear no responsibility in any way for use of Products for the above special purposes. If a Product is intended to be used for an ial purpose, please contact a ROHM sales representative before purchasing.
be control	nd to export or ship overseas any Product or technology specified herein that may led under the Foreign Exchange and the Foreign Trade Law, you will be required to sense or permit under the Law.



Thank you for your accessing to ROHM product informations. More detail product informations and catalogs are available, please contact us.

ROHM Customer Support System

http://www.rohm.com/contact/



#### ООО "ЛайфЭлектроникс"

ИНН 7805602321 КПП 780501001 Р/С 40702810122510004610 ФАКБ "АБСОЛЮТ БАНК" (ЗАО) в г.Санкт-Петербурге К/С 3010181090000000703 БИК 044030703

Компания «Life Electronics» занимается поставками электронных компонентов импортного и отечественного производства от производителей и со складов крупных дистрибьюторов Европы, Америки и Азии.

С конца 2013 года компания активно расширяет линейку поставок компонентов по направлению коаксиальный кабель, кварцевые генераторы и конденсаторы (керамические, пленочные, электролитические), за счёт заключения дистрибьюторских договоров

Мы предлагаем:

- Конкурентоспособные цены и скидки постоянным клиентам.
- Специальные условия для постоянных клиентов.
- Подбор аналогов.
- Поставку компонентов в любых объемах, удовлетворяющих вашим потребностям.
- Приемлемые сроки поставки, возможна ускоренная поставка.
- Доставку товара в любую точку России и стран СНГ.
- Комплексную поставку.
- Работу по проектам и поставку образцов.
- Формирование склада под заказчика.
- Сертификаты соответствия на поставляемую продукцию (по желанию клиента).
- Тестирование поставляемой продукции.
- Поставку компонентов, требующих военную и космическую приемку.
- Входной контроль качества.
- Наличие сертификата ISO.

В составе нашей компании организован Конструкторский отдел, призванный помогать разработчикам, и инженерам.

Конструкторский отдел помогает осуществить:

- Регистрацию проекта у производителя компонентов.
- Техническую поддержку проекта.
- Защиту от снятия компонента с производства.
- Оценку стоимости проекта по компонентам.
- Изготовление тестовой платы монтаж и пусконаладочные работы.



Тел: +7 (812) 336 43 04 (многоканальный) Email: org@lifeelectronics.ru

#### www.lifeelectronics.ru