



Adafruit Joy Bonnet for Raspberry Pi

Created by Phillip Burgess



Last updated on 2018-08-22 03:59:36 PM UTC


Guide Contents

Guide Contents	2
Overview	3
Adafruit Raspberry Pi Zero Case	5
Mini HDMI to HDMI Cable - 5 feet	6
Install & Use	7
Software	7
Install!	7
Advanced Usage	8
Downloads	9
Source Code	9
Files	9
Schematic	9


Overview



Pocket-sized fun is the name of this game, with the Joy Bonnet - our most fun Bonnet ever (no we didn't even think that was possible, either!) This Bonnet fits perfectly on top of your Raspberry Pi Zero (any kind) and gives you adorable hand-held arcade controls. Once you install our script onto your Pi, the controls will act like a keyboard, for easy use with any emulator or media player.



Personally, we found this Bonnet to work best with RetroPie/EmulationStation. On a Pi Zero we could emulate NES and MAME game (our favorites!) but other emulators that don't require more than 1GHz speeds will work OK too, e.g. a N64 emulator won't work, it needs way more power!



Best of all, this Bonnet is fully assembled - no soldering at all is required. You may need to solder headers onto your Pi Zero (or use press-fit headers) but once that's done you're ready to rock. In theory you could also use this with a Pi A+ or B+/2/3 but it wouldn't be very hand-held



Since you'll likely grip the Pi during play, we strongly recommend a comfortable enclosure to go along with it! The Adafruit Pi Zero case works well and is nice and rounded for easy holding



[Adafruit Raspberry Pi Zero Case](#)

\$4.75
IN STOCK

[ADD TO CART](#)



Friendly forum-member [cvadillo](#) suggests (<https://adafru.it/fEw>) slipping the extra piece of plastic underneath the bonnet to support it

A Mini HDMI cable will also make it easy to plug-and-play into your HDMI screen



Mini HDMI to HDMI Cable - 5 feet

\$5.95
IN STOCK

ADD TO CART

Install & Use

Software

Software installation for the Joy Bonnet requires an internet connection. That's a frequent topic already covered in other Pi getting-started guides, so we'll assume here that your Pi is already booted and networked, running Raspbian or a gaming-ready OS like RetroPie. (RetroPie is what we use, and recommend!) [RetroPie has a nice First Installation guide \(https://adafru.it/vbB\)](https://adafru.it/vbB)

You can set up the controls however you like, its easy to change them up later. Just get logged into RetroPie, and setup WiFi. Then get into a terminal either on the HDMI console or by ssh'ing in.

[You may find this easiest if ssh is enabled on the Pi, and then log in with a terminal app. \(https://adafru.it/vbC\)](https://adafru.it/vbC) This lets you **copy-and-paste** the commands that follow, as they're very exact about spelling.

Install!


Enter the following two lines to install support for the buttons and joystick:

```
curl https://raw.githubusercontent.com/adafruit/Raspberry-Pi-Installer-Scripts/master/joy-bonnet.sh > joy-  
sudo bash joy-bonnet.sh
```

When run, this script will offer a couple of options:

- **Disable overscan?** If you answer "Y" this removes the black border around the screen (common on HDMI monitors). Takes effect on next boot.
- **Install gpio-halt utility?** Linux-based systems like the Raspberry Pi don't like it when you just switch off power... there's a specific shutdown process, else the SD card may get corrupted. The gpio-halt tool lets you add one more button between ground and any unused GPIO pin to initiate an orderly shutdown. Gaming OSes like RetroPie already include a shutdown command among their menu options, so you probably do **not** need this, unless you want a dedicated button for it.

When the script finishes you'll be asked whether to reboot. Answer "N" if you plan on installing other software. Either way, **sudo reboot** when done to get the joy bonnet software activated!



```
arm-linux-gnueabihf-gcc -pthread -shared -Wl,-O1 -Wl,-Bsymbolic-functions -Wl,-z,relro -fno-strict-aliasing -DNDEBUG -g -fwrapv -O2 -Wall -Wstrict-prototype  
s -D_FORTIFY_SOURCE=2 -g -fstack-protector-strong -Wformat -Werror=format-securi  
ty -Wl,-z,relro -D_FORTIFY_SOURCE=2 -g -fstack-protector-strong -Wformat -Werror  
=format-security build/temp.linux-armv6l-2.7/evdev/ecodes.o -o build/lib.linux-a  
rmv6l-2.7/evdev/_ecodes.so  
  
Successfully installed evdev  
Cleaning up...  
Installing Adafruit code in /boot...  
  % Total    % Received % Xferd  Average Speed   Time    Time     Time  Current  
                                 Dload  Upload   Total   Spent    Left   Speed  
100 6982  100 6982    0     0  37135      0  --:--:-- --:--:-- --:--:-- 37537  
Configuring system...  
Done.  
  
Settings take effect on next boot.  
  
REBOOT NOW? [y/N] y  
Reboot started...
```

That's it! The script to generate keycodes is now installed and will be run every time the Pi boots

Once RetroPie has restarted, go to the **MENU** and step down to **CONFIGURE INPUT** and select it to re-start the input configuration. The left joystick can be used for up/down/left/right. The right buttons are A B X Y. Middle buttons are Select and Start as labeled. Then you get two more buttons you can set up as left/right shoulder or trigger buttons.

Note that pressing Select+Start will quit out of games, other than that the controls are used in the emulators by generating 'key presses' - see below for how to change the keypresses!



Advanced Usage

If you need to change the key assignments: edit the file `/boot/joyBonnet.py` say with `sudo nano /boot/joyBonnet.py`

Near the top of the code you'll see this table:

```
KEYS= { # EDIT KEYCODES IN THIS TABLE TO YOUR PREFERENCES:
# See /usr/include/linux/input.h for keycode names
# Keyboard      Bonnet      EmulationStation
BUTTON_A: e.KEY_LEFTCTRL, # 'A' button
BUTTON_B: e.KEY_LEFTALT,  # 'B' button
BUTTON_X: e.KEY_Z,        # 'X' button
BUTTON_Y: e.KEY_X,        # 'Y' button
SELECT:   e.KEY_SPACE,    # 'Select' button
START:    e.KEY_ENTER,    # 'Start' button
PLAYER1:  e.KEY_1,        # '#1' button
PLAYER2:  e.KEY_2,        # '#2' button
1000:     e.KEY_UP,       # Analog up
1001:     e.KEY_DOWN,     # Analog down
1002:     e.KEY_LEFT,     # Analog left
1003:     e.KEY_RIGHT,    # Analog right
}
```

'#' lines are human comments and do nothing for the code. The first eight actual elements in the table correspond to the button inputs, while the last four are the joystick directions.

Downloads


Source Code

- Joy Bonnet installer (<https://adafru.it/uza>) and key-press python script (<https://adafru.it/cbl>) available on github!

Files

- EagleCAD PCB files on GitHub (<https://adafru.it/vbE>)

Schematic



Компания «Life Electronics» занимается поставками электронных компонентов импортного и отечественного производства от производителей и со складов крупных дистрибьюторов Европы, Америки и Азии.

С конца 2013 года компания активно расширяет линейку поставок компонентов по направлению коаксиальный кабель, кварцевые генераторы и конденсаторы (керамические, пленочные, электролитические), за счёт заключения дистрибьюторских договоров

Мы предлагаем:

- Конкурентоспособные цены и скидки постоянным клиентам.
- Специальные условия для постоянных клиентов.
- Подбор аналогов.
- Поставку компонентов в любых объемах, удовлетворяющих вашим потребностям.
- Приемлемые сроки поставки, возможна ускоренная поставка.
- Доставку товара в любую точку России и стран СНГ.
- Комплексную поставку.
- Работу по проектам и поставку образцов.
- Формирование склада под заказчика.
- Сертификаты соответствия на поставляемую продукцию (по желанию клиента).
- Тестирование поставляемой продукции.
- Поставку компонентов, требующих военную и космическую приемку.
- Входной контроль качества.
- Наличие сертификата ISO.

В составе нашей компании организован Конструкторский отдел, призванный помогать разработчикам, и инженерам.

Конструкторский отдел помогает осуществить:

- Регистрацию проекта у производителя компонентов.
- Техническую поддержку проекта.
- Защиту от снятия компонента с производства.
- Оценку стоимости проекта по компонентам.
- Изготовление тестовой платы монтаж и пусконаладочные работы.



Тел: +7 (812) 336 43 04 (многоканальный)

Email: org@lifeelectronics.ru

www.lifeelectronics.ru